

AROMA®



instruction manual

ARC-802CUP/ARC-802CUBL

Rice & Grain Cooker

Questions or concerns about your Aroma product?

www.AromaCo.com/Support

1-800-276-6286

DISCOVER
more of our
products!



Digital Rice & Grain
Multicookers



Rice & Grain
Cookers



Electric Kettles



Indoor Grills



...and More!

AROMA®

To Enhance and Enrich Lives.

Here at Aroma we strive to make a difference—to design and distribute products that enhance and enrich people's lives.

Aroma offers an array of exceptional products to make cooking simple and satisfying. Discover other countertop appliances and cookware from our current product lineup to complement your kitchen.

REGISTER YOUR PRODUCT



SCAN TO REGISTER
[AromaCo.com/registration](https://www.AromaCo.com/registration)

Registration is quick and easy.

Be notified of:

- new product releases
- new test kitchen recipes
- sales and promotions
- ...and more!



/AromaHousewares



IMPORTANT SAFEGUARDS

Basic safety precautions should always be followed when using electrical appliances, including the following:

1. **Important: Read all instructions carefully before first use.**
2. Do not touch hot surfaces. Use the handles or knobs.
3. Use only on a level, dry and heat-resistant surface.
4. To protect against fire, electrical shock and injury to persons, do not immerse the power cord, plug or appliance in water or any other liquid. See instructions for cleaning.
5. Close supervision is necessary when the appliance is used by or near children.
6. Unplug from the wall outlet when not in use and before cleaning. Allow the unit to completely cool before putting on or removing parts and before cleaning the appliance.
7. Do not operate any appliance with a damaged power cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact Aroma® customer service for examination, repair or adjustment.
8. The use of accessory attachments not recommended by Aroma® Housewares may result in fire, electrical shock or injury.
9. Do not use outdoors.
10. Do not allow the power cord to touch hot surfaces or hang over the edge of a counter or table.
11. Do not place the appliance on or near a hot gas or electric burner or in a heated oven.
12. Do not use the appliance for other than its intended use.
13. Extreme caution must be used when moving the appliance containing hot food, oil or liquids.
14. Do not touch, cover or obstruct the steam vent on the top of the appliance as it is extremely hot and may cause scalding.
15. Use only with a 120V AC power outlet.
16. Always unplug from the plug gripping area. Never pull on the cord.
17. The appliance should be operated on a separate electrical circuit from other operating appliances. If the electrical circuit is overloaded with other appliances, the appliance may not operate properly.
18. Always make sure the exterior of the inner pot is dry prior to use. If the inner pot is returned to the appliance when wet, it may damage or cause the product to malfunction.
19. Use extreme caution when opening the lid during or after cooking. Hot steam will escape and may cause scalding.
20. Food should not be left in the appliance on **Warm** mode for more than 12 hours.
21. To prevent damage or deformation, do not use the inner pot on a stovetop or burner.
22. To disconnect, flip the cook switch to **Warm** then remove the plug from the wall outlet.
23. **CAUTION:** To reduce the risk of electrical shock, cook only in the removable inner pot provided.
24. Do not wrap or tie the power cord around the appliance.
25. **WARNING:** Spilled food can cause serious burns. Keep the appliance and power cord away from children. Never drape the power cord over the edge of a counter, never use outlet below counter, and never use with an extension cord.
26. **CAUTION:** Intended for countertop use only.
27. **CAUTION:** Do not use for deep frying.

SAVE THESE INSTRUCTIONS



IMPORTANT SAFEGUARDS

Short Cord Instructions

A short power-supply cord is provided to reduce the risks resulting from it being grabbed by children, and becoming entangled in or tripping over a longer cord.

	<h3>WARNING</h3> <p>Spilled food can cause serious burns. Keep appliance & cord away from children.</p> <p>NEVER</p> <ul style="list-style-type: none">• Drape cord over edge of counter.• Use outlet below counter.• Use extension cord.
--	--


Polarized Plug

This appliance has a polarized plug (one blade is wider than the other); follow the instructions below:

To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.

Parts Identification



THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.

Controls/Functions

Cook

Simply press the switch down to begin cooking rice, grains, and a variety of other meals.

Warm

Automatically switches to **Warm** at the end of the cooking cycle; perfect for keeping rice at a ready-to-serve temperature.

*This product is protected by one or more patent applications.
Patent Pending Application Number: 18/951560

BEFORE FIRST USE

1. Read all instructions and important safeguards.
2. Remove all packaging materials and check that all items have been received in good condition.
3. Tear up all plastic bags and dispose of them properly as they can pose a risk to children.
4. Remove the inner pot from the cooker and wash with warm, soapy water. Rinse and dry thoroughly before returning to the cooker.
5. Wash all other accessories in warm, soapy water. Rinse and dry thoroughly.
6. Wipe the cooker's body clean with a damp cloth.
.....

TO CLEAN

1. Remove the inner pot when the cooker has completely cooled.
2. Hand wash the inner pot and all accessories using warm, soapy water or place on the top rack of the dishwasher.
3. Wipe the cooker's body clean with a damp cloth.
4. Thoroughly dry the cooker's body, inner lid and all accessories. Reassemble for next use.
.....

TROUBLESHOOTING

Rice is too dry/hard after cooking.

- If your rice is dry or hard/chewy when the cooker switches to **Warm**, additional water and cooking time will soften the rice. Depending on how dry your rice is, add ½ to 1 cup of water and stir thoroughly. Place the lid back on and press the cook switch down. When the cooker switches to **Warm** mode, open the lid and stir the rice to check the consistency. Repeat as necessary until rice is soft and moist.

Rice is too moist/soggy after cooking.

- If your rice is still too moist or soggy when the cooker switches to **Warm**, use the serving spatula to stir the rice. This will redistribute the bottom (moist) part of the rice as well as release excess moisture. Place the lid back on and allow the cooker to remain on **Warm** mode for 10-30 minutes as needed, opening the lid and stirring periodically to release excess moisture.

6.



Caution:

Do not use harsh abrasive cleaners, scouring pads or products that are not considered safe to use on ceramic coatings.

We recommend hand washing the inner pot with warm, soapy water to lengthen its lifespan and avoid damage over time. If washing in a dishwasher, a slight discoloration to the inner pot may occur. This is cosmetic and will not negatively affect performance.

Before placing the inner pot into the cooker, check that the inner pot is dry and free of debris. Adding the inner pot when wet may damage the cooker.

Note:

• Any other servicing should be performed by Aroma® Housewares.

• Not satisfied with your Aroma® purchase? Our product experts can help! **Before returning, please contact Customer Service at 1-800-276-6286** for product support, helpful tips and more!

Helpful Hints:

The provided rice measuring cup is equivalent to a ¾ standard U.S. cup.



RICE & GRAIN

1. Measure rice or grain using the provided measuring cup. Overfill the cup slightly, then level it off at the brim of the cup for an accurate measurement.
2. Rinse measured rice in a bowl of water before adding to the inner pot. For rice, rinse for 10 seconds and drain the water. Repeat this process at least 2 times, or until the water runs clear. For other grains, see the package instructions.
3. Add rinsed rice to the inner pot. For white or brown rice, fill the inner pot with water to the line that matches the number of cups of uncooked rice added. For other grains, see "Grain & Water Measurement Table" on page 10.
4. Place the inner pot into the cooker then place the lid on securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the cook switch down. The cook indicator light will illuminate as the cooker begins heating.
7. Once rice is ready, the cook switch will automatically flip up and the cooker will switch to **Warm**.
8. For best results, stir the rice with the serving spatula to distribute any remaining moisture.
9. When finished serving, turn the cooker off by unplugging the power cord.
.....


SOUP

1. Add ingredients to the inner pot, up to the maximum water line (2).
2. Carefully place the pot inside the rice cooker. To prevent boiling over, leave the top open without a lid.
3. Plug the power cord into an available 120V AC wall outlet.
4. Press the cook switch down. The cook indicator light will illuminate as the rice cooker begins cooking.
5. Stir occasionally with a long-handled wooden spoon or heat-safe utensil.
6. Once food is fully cooked, flip the cook switch up to switch the rice cooker to **Warm** mode.
7. When finished serving, turn the rice cooker off by unplugging the power cord.
.....



Caution:

Do not use the provided serving spatula to stir hot soup. It is not intended to be used in contact with high temperatures. Use a long-handled heat-safe utensil to stir food while cooking.



To avoid boiling dry when preparing soup, **do not allow ingredients to cook for longer than one hour.**

After cooking, the inner pot will be very hot. Be sure to use heat-resistant gloves or protective oven mitts to remove the inner pot from the cooker.



Note:

- Because rice varieties may vary in their make-up, results may differ.
- Food should not be left in the cooker on **Warm** for more than 12 hours.
- For best results, we recommend rinsing rice and grains in a bowl of water before cooking. Avoid using a strainer or colander, which may not be as effective in removing excess starch and may affect the final texture.

7.

STEAM

- Using the provided measuring cup, add 1 cup of water to the inner pot.
- Place the inner pot into the cooker.
- Place desired food in the provided steam tray. For storing the steam tray inside the inner pot (see **Figure A**), no ring is needed. For setting the steam tray above the inner pot (see **Figure B**), use the provided ring and ensure it is placed with the correct side up. Securely cover the steam tray with the lid.
- Plug the power cord into an available 120V AC outlet.
- Press the cook switch down. The cook indicator light will illuminate as the cooker begins heating. For suggested steaming times for meat and vegetables, see "Meat & Vegetable Steaming Tables" on page 9.
- Once the suggested amount of time has passed, remove the lid using caution and check food for doneness.
- Remove steamed food immediately once it is cooked. Wear protective heat-resistant gloves to prevent injury as the steam tray will be hot.
- When finished steaming, turn the cooker off by unplugging the power cord.



STEAM & COOK

- Follow steps 1 through 3 of "Rice & Grain" on page 7 to measure, rinse, and add rice or grain to the inner pot.
- Place the inner pot into the cooker.
- Place the provided ring on top of the inner pot, ensuring the correct side is facing up.
- Set the steam tray on top of the ring (see **Figure B**) and add your desired food. Then, securely cover the steam tray with the lid.
- Plug the power cord into a 120V AC wall outlet.
- Press the cook switch down. The cook indicator

continued on the next page >>



Caution:

Do not attempt to cook more than 1 cup of uncooked rice when steaming and cooking simultaneously.

Do not open the lid or add ingredients while the rice is cooking. Opening the lid mid-cycle may cause hot steam or boiling water to escape suddenly, posing a burn risk.

Level the surface of the rice before cooking to ensure even cooking. Failure to do so may cause the cooked rice to touch the steaming tray.

Note:

Delicate foods (e.g., leafy vegetables) might overcook if steamed for the entire rice cooking cycle.

Dense foods (e.g., potatoes, corn, pumpkin, fish in foil) may not fully cook during the rice cycle. Cut into smaller pieces or reduce the quantity for even cooking. If additional steaming is needed, remove the rice and refer to page 8 for 'Steam' instructions.

Pro Tip:

For optimal results, let the rice rest on **Warm** for 10–15 minutes after cooking. This will allow the heat and moisture to distribute more evenly, improving both texture and flavor.

STEAM & COOK (CONT.)

light will turn on, and the cooker will begin heating.

- Once the rice or grain is ready, the cook switch will automatically flip up, and the cooker will switch to **Warm** mode.
- Carefully open the lid and check steamed food for doneness.
- Remove the steam tray. Wear a protective heat-resistant glove to prevent injury, as the steam tray will be hot.
- When finished serving, turn off the cooker by unplugging the power cord.

Meat & Vegetable Steaming Tables

Meat	Steaming Time	Safe Internal Temperature
Fish	25 Min.	140°F
Chicken	30 Min.	165°F
Pork	30 Min.	160°F
Beef	Medium = 25 Min. Medium-Well = 30 Min. Well = 33 Min.	160°F

Vegetable	Steaming Time
Asparagus	15-17 Minutes
Broccoli	10-12 Minutes
Cabbage	7-9 Minutes
Carrots	15-17 Minutes
Cauliflower	10-12 Minutes
Corn	15-17 Minutes
Green Beans	15-17 Minutes
Peas	6-8 Minutes
Spinach	4-6 Minutes
Squash	15-17 Minutes
Zucchini	15-17 Minutes
Potatoes	28-33 Minutes

When steaming, Aroma® recommends using 1 cup of water with the provided rice measuring cup.

Helpful Hints:

Since most vegetables only absorb a small amount of water, there is no need to increase the amount of water with a larger serving of vegetables.

To ensure meat tastes its best and to prevent food-borne illness, check that the meat is completely cooked prior to serving. If the meat is still uncooked, simply add more water to the inner pot and repeat the steaming process until the meat is adequately cooked.

Note:

Altitude, humidity and outside temperature will affect cooking times.

These steaming charts are for reference only. Actual cooking times may vary.


Rice & Water Measurement Table

Uncooked Rice*	Water: Using the Water Line (inside inner pot)	Approx. Cooked Rice Yield*	Cooking Times
1 Cup	White Rice: Line 1 Brown Rice: Line 1	White Rice: 2 Cups Brown Rice: 2 Cups	White Rice: 20-25 Min. Brown Rice: 33-38 Min.
1½ Cups	White Rice: Line 1½ Brown Rice: --	White Rice: 3 Cups Brown Rice: --	White Rice: 23-28 Min. Brown Rice: --
2 Cups	White Rice: Line 2 Brown Rice: --	White Rice: 4 Cups Brown Rice: --	White Rice: 26-31 Min. Brown Rice: --

Grain & Water Measurement Table

Grain	Uncooked Grain*	Liquid*	Approx. Cooked Grain Yield*	Max. Uncooked Grain*
Quinoa	1 Part	1½ Part	2 Part	1 Cup
Couscous	1 Part	1 Part	2 Part	1 Cup
Oatmeal	1 Part	2 Parts	2 Part	½ Cup

*Cups referenced are with the included measuring cup
1 Rice Measuring Cup = ¾ U.S. Cup (180ml)



LIMITED WARRANTY

Aroma Housewares Company warrants its products against defects in material and workmanship for one year from the date the customer takes possession of the product in the United States. For in-store purchases, this is the purchase date. For online or delivery orders, this is the delivery date.

Within this warranty period, Aroma Housewares Company will repair or replace, at its discretion, defective parts at no charge. Proof of the date of purchase, such as the original dated sales receipt, will be required with any request for warranty repair or replacement. All liability is limited to the amount of the purchase price.

This warranty does not apply if the warranty period expired; the product has been modified by any unauthorized service center or personnel; the defect was subject to abuse, improper use not conforming to product manual instructions, or environmental conditions more severe than those specified in the manual and specification, neglect of the owner or improper installation; the defect was subject to Force Majeure such as flood, fire, lightning, earthquake, other natural calamities, war. The warranty excludes accessories and replacement parts. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 120V ~ 60Hz).

Aroma's sole obligation under the warranty shall be to replace the defective product with a working one or a similar model of equivalent value, if the same model is not available, in the occurrence of any failure or defect covered under the warranty during the warranty period. Refurbished items or items not purchased through an authorized retailer are not eligible for warranty claims. Transportation charges on parts, or products in whole, submitted for repair or replacement, under this warranty, must be borne by the purchaser.

This warranty gives you specific legal rights, which may vary from state to state, and does not cover areas outside the United States.

Note:

- Proof of purchase is required for all warranty claims.
- Failure to register your product will not diminish your warranty rights.
- Not satisfied with your Aroma® purchase? Our product experts can help! **Before returning, please contact Customer Service at 1-800-276-6286** for product support, helpful tips and more!

SERVICE & SUPPORT

In the event of a warranty claim, or if service is required for this product, please contact Aroma® customer service toll-free at:

1-800-276-6286 | CustomerService@AromaCo.com
M-F, 8:00am-4:00pm, Pacific Time

www.AromaCo.com
Aroma Housewares Company
6469 Flanders Drive, San Diego, CA 92121, U.S.A.

Note:

- **Maximum capacity: 2 cups of uncooked white rice or 1 cup of uncooked brown rice.**
- **Minimum capacity: 1 cup of uncooked white or brown rice.**
- Opening the lid during the cooking cycle causes a loss of heat and steam. Cooking time may be prolonged if the lid is opened before the rice is finished.
- For best results, we recommend rinsing rice and grains in a bowl of water before cooking. Avoid using a strainer or colander, which may not be as effective in removing excess starch and may affect the final texture.
- Cooking times are approximate. Altitude, humidity and external temperature will affect cooking time.



To Enhance and Enrich Lives.



www.AromaCo.com