

AROMA®



instruction manual

SRC-860NGU

Rice & Grain Cooker

Questions or concerns about your Aroma product?

www.AromaCo.com/Support

1-800-276-6286

DISCOVER
more of our
products!



Digital Rice & Grain
Multicookers



Rice & Grain
Cookers



Electric Kettles



Indoor Grills



...and More!

AROMA®

To Enhance and Enrich Lives.

Here at Aroma we strive to make a difference—to design and distribute products that enhance and enrich people's lives.

Aroma offers an array of exceptional products to make cooking simple and satisfying. Discover other countertop appliances and cookware from our current product lineup to complement your kitchen.

REGISTER YOUR PRODUCT



SCAN TO REGISTER
[AromaCo.com/registration](https://www.AromaCo.com/registration)

Registration is quick and easy.

Be notified of:

- new product releases
- new test kitchen recipes
- sales and promotions
- ...and more!



/AromaHousewares



IMPORTANT SAFEGUARDS

Basic safety precautions should always be followed when using electrical appliances, including the following:

1. **Important: Read all instructions carefully before first use.**
2. Do not touch hot surfaces. Use the handles or knobs.
3. Use only on a level, dry and heat-resistant surface.
4. To protect against fire, electrical shock and injury to persons, do not immerse the power cord, plug or appliance in water or any other liquid. See instructions for cleaning.
5. Close supervision is necessary when the appliance is used by or near children.
6. Unplug from the wall outlet when not in use and before cleaning. Allow the unit to completely cool before putting on or removing parts and before cleaning the appliance.
7. Do not operate any appliance with a damaged power cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact Aroma® customer service for examination, repair or adjustment.
8. The use of accessory attachments not recommended by Aroma® Housewares may result in fire, electrical shock or injury.
9. Do not use outdoors.
10. Do not allow the power cord to touch hot surfaces or hang over the edge of a counter or table.
11. Do not place the appliance on or near a hot gas or electric burner or in a heated oven.
12. Do not use the appliance for other than its intended use.
13. Extreme caution must be used when moving the appliance containing hot food, oil or liquids.
14. Do not touch, cover or obstruct the steam vent on the top of the appliance as it is extremely hot and may cause scalding.
15. Use only with a 120V AC power outlet.
16. Always unplug from the plug gripping area. Never pull on the cord.
17. The appliance should be operated on a separate electrical circuit from other operating appliances. If the electrical circuit is overloaded with other appliances, the appliance may not operate properly.
18. Always make sure the exterior of the inner pot is dry prior to use. If the inner pot is returned to the appliance when wet, it may damage or cause the product to malfunction.
19. Use extreme caution when opening the lid during or after cooking. Hot steam will escape and may cause scalding.
20. Food should not be left in the appliance on **Warm** mode for more than 12 hours.
21. To prevent damage or deformation, do not use the inner pot on a stovetop or burner.
22. To disconnect, flip the cook switch to **Warm** then remove the plug from the wall outlet.
23. **CAUTION:** To reduce the risk of electrical shock, cook only in the removable inner pot provided.
24. Do not wrap or tie the power cord around the appliance.
25. **WARNING:** Spilled food can cause serious burns. Keep the appliance and power cord away from children. Never drape the power cord over the edge of a counter, never use outlet below counter, and never use with an extension cord.
26. **CAUTION:** Intended for countertop use only.
27. **CAUTION:** Do not use for deep frying.

SAVE THESE INSTRUCTIONS



IMPORTANT SAFEGUARDS

Parts Identification

Short Cord Instructions

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.



	<h3>WARNING</h3> <p>Spilled food can cause serious burns. Keep appliance & cord away from children.</p> <p>NEVER</p> <ul style="list-style-type: none">• Drape cord over edge of counter.• Use outlet below counter.• Use extension cord.
--	--

Polarized Plug

This appliance has a polarized plug (one blade is wider than the other); follow the instructions below:

To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.



THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.

Controls/Functions

Cook

Simply press the switch down to begin cooking rice, grains, and a variety of other meals.

Warm

Automatically switches to **Warm** at the end of the cooking cycle; perfect for keeping rice at a ready-to-serve temperature.

BEFORE FIRST USE

1. **Read all instructions and important safeguards.**
2. Remove all packaging materials and check that all items have been received in good condition.
3. Tear up all plastic bags and dispose of them properly as they can pose a risk to children.
4. Remove the inner pot from the cooker and wash with warm, soapy water. Rinse and dry thoroughly before returning to the cooker.
5. Wash all other accessories in warm, soapy water. Rinse and dry thoroughly.
6. Wipe the cooker's body clean with a damp cloth.
.....

TO CLEAN

1. Remove the inner pot when the cooker has completely cooled.
2. Hand wash the inner pot and all accessories using warm, soapy water or place on the top rack of the dishwasher.
3. Wipe the cooker's body clean with a damp cloth.
4. Thoroughly dry the cooker's body, inner lid and all accessories. Reassemble for next use.
.....



Caution:

Do not use harsh abrasive cleaners, scouring pads or products that are not considered safe to use on nonstick coatings.

We recommend hand washing the inner pot with warm, soapy water to lengthen its lifespan and avoid damage over time. If washing in a dishwasher, a slight discoloration to the inner pot may occur. This is cosmetic and will not negatively affect performance.

Before placing the inner pot into the cooker, check that the inner pot is dry and free of debris. Adding the inner pot when wet may damage the cooker.

TROUBLESHOOTING

Rice is too dry/hard after cooking.

- If your rice is dry or hard/chewy when the cooker switches to **Warm**, additional water and cooking time will soften the rice. Depending on how dry your rice is, add ½ to 1 cup of water and stir thoroughly. Place the lid back on and press the cook switch down. When the cooker switches to **Warm** mode, open the lid and stir the rice to check the consistency. Repeat as necessary until rice is soft and moist.

Rice is too moist/soggy after cooking.

- If your rice is still too moist or soggy when the cooker switches to **Warm**, use the serving spatula to stir the rice. This will redistribute the bottom (moist) part of the rice as well as release excess moisture. Place the lid back on and allow the cooker to remain on **Warm** mode for 10-30 minutes as needed, opening the lid and stirring periodically to release excess moisture.
.....

Note:

- Any other servicing should be performed by Aroma® Housewares.
- Not satisfied with your Aroma® purchase? Our product experts can help! **Before returning, please contact Customer Service at 1-800-276-6286** for product support, helpful tips and more!

RICE & GRAIN

1. Using the provided rice measuring cup, add rice or grain to the inner pot.
2. For white or brown rice, rinse for 10 seconds and drain the water. Repeat this process at least 2 times, or until the water runs clear. For other grains, see the package instructions.
3. For white rice, fill the inner pot with water to the line that matches the number of cups of uncooked rice added. For brown rice and other grains, see the "Rice/Grain & Water Measurement Tables" on page 12.
4. Place the inner pot into the cooker then place the lid on securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the cook switch down. The cook indicator light will illuminate as the cooker begins heating.
7. Once rice or grain is ready, the cook switch will automatically flip up and the cooker will switch to **Warm**.
8. For best results, stir the grain with the serving spatula to distribute any remaining moisture.
9. When finished serving, turn the cooker off by unplugging the power cord.
.....



Caution:


Before placing the inner pot into the cooker, check that the inner pot is dry and free of debris. Adding the inner pot when wet may damage the cooker.

Note:

- Because rice varieties may vary in their make-up, results may differ.
- Food should not be left in the cooker on **Warm** for more than 12 hours.
- For best results, we recommend rinsing rice and grains in a bowl of water before cooking. Avoid using a strainer or colander, which may not be as effective in removing excess starch and may affect the final texture.

Helpful Hints:

The provided rice measuring cup is equivalent to a ¾ standard U.S. cup.




SOUP, CHILI, OR STEW

1. Add ingredients to the inner pot.
2. Lower the inner pot into the cooker and place the lid on top.
3. Plug the power cord into an available 120V AC wall outlet.
4. Press the cook switch down. The cook indicator light will illuminate as the rice cooker begins cooking.
5. Using caution to avoid escaping steam, remove the lid and stir occasionally with a long-handled wooden spatula.
6. Once food is fully cooked, flip the cook switch up to switch the rice cooker to **Warm** mode.
7. When finished serving, turn the rice cooker off by unplugging the power cord.
.....



Caution:



Do not use the provided serving spatula to stir hot soup. It is not intended to be used in contact with high temperatures. Use a long-handled heat-safe utensil to stir food while cooking.



To avoid boiling dry when preparing soup, **do not allow ingredients to cook for longer than one hour.**

STEAM

- Using the provided measuring cup, add 2 cups of water to the inner pot.
- Place the inner pot into the cooker.
- Place desired food in the provided steam tray. For setting the steam tray inside the inner pot (see **Figure A**), no ring is needed. For setting the steam tray above the inner pot (see **Figure B**), use the provided ring and ensure it is placed with the correct side up. Securely cover the steam tray with the lid.
- Plug the power cord into an available 120V AC outlet.
- Press the cook switch down. The cook indicator light will illuminate as the cooker begins heating. For suggested steaming times for meat and vegetables, see "Meat & Vegetable Steaming Tables" on page 11.
- Once the suggested amount of time has passed, remove the lid using caution and check food for doneness.
- Remove steamed food immediately once it is cooked. Wear protective heat-resistant gloves to prevent injury as the steam tray will be hot.
- When finished steaming, turn the cooker off by unplugging the power cord.



STEAM & COOK

To steam foods while cooking rice or grain below, begin by following steps 1 through 6 of "Rice & Grain" on page 8.

- Place desired food in the provided steam tray. Use the provided ring to set the steam tray above the inner pot (see **Figure B**), ensuring the ring is placed with the correct side up. Then, securely cover the steam tray with the lid.
- Cook food according to the "Meat & Vegetable Steaming Tables" on page 10.
- Once the suggested amount of time has passed, remove the lid using caution and check food for doneness.

continued on the next page >>



Caution:

Before placing the inner pot into the cooker, check that it is dry and free of debris. Adding the inner pot when wet may damage the cooker.

Note:

Food can be steamed at any time while rice cooks. However, for best results, food should be steamed towards the end of the rice cooking cycle. This will allow for rice and steamed food to be ready at the same time. See the "Rice/Grain & Water Measurement Tables" on page 12 for approximate cooking times.

Food should not be left in the cooker on **Warm** for more than 12 hours.

STEAM & COOK (CONT.)

- If food is finished steaming, remove the steam tray. Wear protective heat-resistant gloves to prevent injury as the steam tray will be hot.
- Place the lid back on and allow the cooking cycle to continue.
- Once rice or grain is ready, the cook switch will automatically flip up and the cooker will switch to **Warm**.
- When finished serving, turn the cooker off by unplugging the power cord.

Meat & Vegetable Steaming Tables

Meat	Steaming Time	Safe Internal Temperature
Fish	25 Min.	140°F
Chicken	30 Min.	165°F
Pork	30 Min.	160°F
Beef	Medium = 25 Min. Medium-Well = 30 Min. Well = 33 Min.	160°F

Vegetable	Steaming Time
Asparagus	9-11 Minutes
Broccoli	6-8 Minutes
Cabbage	5-7 Minutes
Carrots	11-13 Minutes
Cauliflower	7-9 Minutes
Corn on the Cob	12-16 Minutes
Green Beans	9-11 Minutes
Peas	4-6 Minutes
Spinach	2-4 Minutes
Squash	9-11 Minutes
Zucchini	9-11 Minutes
Potatoes	28-33 Minutes

*When steaming, Aroma® recommends using 2 cups of water with the provided rice measuring cup.

Helpful Hints:

Smaller foods may be placed on a heat resistant dish and then placed onto the steam tray. Parchment paper or aluminum foil may be used as well. Place the paper foil in the center of the steam tray and ensure it does not create a seal along the bottom of the steam tray. For best results, it is recommended to puncture small holes in the paper/foil.

Since most vegetables only absorb a small amount of water, there is no need to increase the amount of water with a larger serving of vegetables.


To ensure meat tastes its best and to prevent food-borne illness, check that the meat is completely cooked prior to serving. If the meat is still uncooked, simply add more water to the inner pot and repeat the steaming process until the meat is adequately cooked.

Rice & Water

Measurement Table

Uncooked Rice*	Water: Using the Water Line (inside pot)	Approx. Cooked Rice Yield*	Cooking Times
2 Cups	White Rice: Line 2 Brown Rice: Line 2	4 Cups	White Rice: 18-23 Min. Brown Rice: 28-33 Min.
3 Cups	White Rice: Line 3 Brown Rice: Line 3	6 Cups	White Rice: 21-26 Min. Brown Rice: 32-37 Min.
4 Cups	White Rice: Line 4 Brown Rice: Line 4	8 Cups	White Rice: 24-29 Min. Brown Rice: 36-41 Min.
5 Cups	White Rice: Line 5 Brown Rice: Line 5	10 Cups	White Rice: 27-32 Min. Brown Rice: 40-45 Min.
6 Cups	White Rice: Line 6 Brown Rice: Line 6	12 Cups	White Rice: 30-35 Min. Brown Rice: 44-49 Min.
7 Cups	White Rice: Line 7 Brown Rice: Line 7	14 Cups	White Rice: 33-38 Min. Brown Rice: 48-53 Min.
8 Cups	White Rice: Line 8 Brown Rice: --	16 Cups	White Rice: 35-42 Min. Brown Rice: --
9 Cups	White Rice: Line 9 Brown Rice: --	18 Cups	White Rice: 37-44 Min. Brown Rice: --
10 Cups	White Rice: Line 10 Brown Rice: --	20 Cups	White Rice: 40-47 Min. Brown Rice: --

*Cups referenced are with the included measuring cup
(1 Rice Measuring Cup = ¾ U.S. Cup)




Grain & Water

Measurement Table

Grain	Uncooked Grain	Liquid	Approx. Cooked Grain Yield	Max. Uncooked Grain*
Barley	1 Part	3 Parts	2½ Parts	1 Cup
Bulgur	1 Part	2½ Parts	2½ Parts	1½ Cups
Couscous	1 Part	1 Part	2 Parts	7 Cups
Quinoa	1 Part	1½ Parts	2½ Parts	6 Cups

*Cups referenced are with the included measuring cup
(1 Rice Measuring Cup = ¾ U.S. Cup)



Note:

- Maximum capacity: 10 cups of uncooked white rice or 7 cups of uncooked brown rice.
- Minimum capacity: 2 cups of uncooked white or brown rice.
- Opening the lid during the cooking cycle causes a loss of heat and steam. Cooking time may be prolonged if the lid is opened before the rice is finished.
- For best results, we recommend rinsing rice and grains in a bowl of water before cooking. Avoid using a strainer or colander, which may not be as effective in removing excess starch and may affect the final texture.

Note:

- Cooking times are approximate. Altitude, humidity and external temperature will affect cooking time.
- For best results when cooking barley or bulgur, let both grains sit on **Warm** for 10 minutes before serving.
- If softer grains are desired, add an additional ½ cup of water or liquid.

14.

[illegible]

This warranty gives you specific legal rights, which may vary from state to state, and does not cover areas outside the United States.

Aroma Housewares Company
6469 Flanders Drive, San Diego, CA 92121, U.S.A.

- Proof of purchase is required for all warranty claims.
- Failure to register your product will not diminish your warranty rights.
- Not satisfied with your Aroma® purchase? Our product experts can help! **Before returning, please contact Customer Service at 1-800-276-6286** for product support, helpful tips and more!



To Enhance and Enrich Lives.



www.AromaCo.com